

Epson Ultra Glossy Photo Paper - photo paper - glossy - 50 sheet(s) - 130 x 180 mm




In Stock(1)

SKU	C13S041944
Product Description:	Epson Ultra Glossy Photo Paper - photo paper - glossy - 50 sheet(s) - 130 x 180 mm
Product Type:	Photo paper
Surface Finish:	Glossy
Media Size:	130 x 180 mm
Printing Technology:	Ink-jet
Included Qty:	50 sheet(s)
Compatible with:	EcoTank ET-1810, 2710, 2711, 2712, 2714, 2715, 2720, 2721, 2726, 2750, 2751, 2756, 2810, 2811, 2812, 2814, 2815, 2820, 2821, 2825, 2826, 2850, 2851, 2856, 3750, 4700, 4750, 4800, 4850, 7700, 7750; Expression Home HD XP-15000; Expression Premium XP-540, 6000, 6005, 900; SureColor P800

Media

Media Type:	Photo paper
Surface Finish:	Glossy
Media Sizes:	130 x 180 mm
Printing Technology:	Ink-jet
Included Qty:	50 sheet(s)

Compatibility Information



Compatibility Information

Epson EcoTank ET-1810, ET-2710, ET-2710 Unlimited, ET-2711, ET-2712, ET-2714, ET-2715, ET-2720, ET-2720 All-in-One Supertank Printer, ET-2720 Unlimited, ET-2721, ET-2721 Unlimited, ET-2726, ET-2750, ET-2750U, ET-2751, ET-2756, ET-2810, ET-2811, ET-2812, ET-2814, ET-2815, ET-2820, ET-2821, ET-2825, ET-2826, ET-2850, ET-2850U, ET-2851, ET-2856, ET-3750, ET-4700, ET-4700 Unlimited, ET-4750, ET-4750 Unlimited, ET-4750U, ET-4800, ET-4850, ET-4850U, ET-7700, ET-7750 | Epson Expression Home XP-320, XP-33, XP-420, XP-424, XP-530 | Epson Expression Home HD XP-15000 | Epson Expression Photo XP-55, XP-750, XP-760, XP-850, XP-860, XP-950, XP-960 | Epson Expression Premium XP-530, XP-540, XP-540 Media Bundle, XP-6000, XP-6005, XP-605, XP-610, XP-615, XP-620, XP-630, XP-635, XP-640, XP-645, XP-810, XP-900, XP-900 Stickers | Epson Stylus C87, C87 Plus, CX3700, CX4700, CX4900, CX5900, D120, D88, D88 Photo Edition, DX3800, DX3850, DX4000, DX4050, DX4250, DX4400, DX4450, DX4800, DX5000, DX6000, DX6050, DX7000F, DX7400, DX7450, DX8400, DX8450, DX9400F, Pro 3880, Pro 3880 Mirage Edition, S20, S21, SX100, SX105, SX110, SX115, SX130, SX200, SX205, SX210, SX215, SX235W, SX400, SX405, SX410, SX415, SX435W, SX445W, SX510W, SX515W, SX535WD, SX600FW, SX610FW | Epson Stylus Office B1100, B40W, B42WD, BX300F, BX305F, BX310FN, BX320FW, BX600FW, BX610FW, BX635FWD, BX925FWD | Epson Stylus Photo 1400, PX650, PX660, PX700W, PX710W, PX730WD, PX810FW, PX830FWD, R1900, R220, R285, R2880, RX520, RX560, RX585, RX640, RX685 | Epson SureColor P800 Designer Edition, SC-P800 | Epson WorkForce WF-2010W, WF-2630, WF-2630WF, WF-2650DWF, WF-2660DWF, WF-2750DWF, WF-2760DWF, WF-3620DWF, WF-3620DWF Stickers, WF-3640DTWF, WF-7110DTW, WF-7515, WF-7610DWF | Epson WorkForce Pro WF-4630DWF, WF-4640DTWF, WF-6090DW, WF-6590DWF, WF-R5190 DTW Flex, WF-R5190 DTW Flex BAM, WF-R5690 DTWF Flex BAM, WF-R5690DTWF Flex, WF-R8590 D3TWFC Flex, WF-R8590 DTWFC Flex, WF-

Compatible
with:

Compatibility Information

